

For all your roasting essentials. Consisting of one enamelled Roasting Pan, one stainless steel Roasting Cradle and two sets of Telescopic Runners.



Product Details

FEATURES

Roasting Dish

Roasting Cradle

Oven Runners

BENEFITS

Roasting Dish

Enjoy hassle-free roasting with the Westinghouse Roasting Dish. This roasting dish has a deep basin ensuring all roasting juices are captured while the roast is cooking. This means less chance of the hot juices spilling over when pulling the roasting dish out of the oven so you'll have a perfectly cooked roast and a perfectly clean oven.

Roasting Cradle

No matter what shape or size, the Westinghouse Roasting Cradle with its v-shaped indentation, secures the roast and other roasting ingredients neatly in their intended position. The raised side arms make removing the roast from the roasting dish a much safer and easier experience.

Oven Runners

Cooking is a whole lot easier with the Westinghouse Oven Runners. With two additional sets of oven runners, you can safely pull the oven racks and trays all the way out of the oven. So not only is loading and unloading the oven more efficient, but it's also easier to check your cooking and stir your food. Better access means better results for every dish.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	1
Product Relates to	Oven

SHIPPING

Shipping Weight (Kg)	2.9
Pack Dimensions Height (mm)	475
Pack Dimension Width (mm)	375
Pack Dimension Depth (mm)	82

FEATURES

Accessory Other Features	Quick & easy installation,Non-stick surface
--------------------------	---

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz