


**Oven Runners. Tasting, stirring, and basting – it's a breeze with the Westinghouse oven runners kit. Each pack consists of three sets of Telescopic Runners.**



# Product Details

## FEATURES

---

Oven Runners

Tray Fastener

---

## BENEFITS

---

**Three Sets Oven Runners**  
Cooking is a whole lot easier with the Westinghouse Oven Runners. With three additional sets of oven runners, you can safely pull the oven racks and trays all the way out of the oven. So not only is loading and unloading the oven more efficient, but its also easier to check your cooking and stir your food. Better access means better results for every dish.

**Tray Fastener**  
The Westinghouse Oven Runners are designed to grab and hold your Westinghouse Oven Racks, Roasting Dishes and Baking Trays, giving you a safe and secure slide every time.

---

# Specifications

## PRODUCT PROFILE

Domestic warranty details (yrs)	1
Product Relates to	Oven

## DIMENSIONS

Total height (mm)	45
Total width (mm)	390
Total depth (mm)	65

## FEATURES

Accessory Other Features	Quick & easy installation
--------------------------	---------------------------

# Terms and Conditions

## IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

## PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

## WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

### ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: [customercare@electrolux.com.au](mailto:customercare@electrolux.com.au)

web: [www.electrolux.com.au](http://www.electrolux.com.au)

### ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: [customercare@electrolux.co.nz](mailto:customercare@electrolux.co.nz)

web: [www.electrolux.co.nz](http://www.electrolux.co.nz)