


The oil drip tray is custom designed to easily capture and remove excess oil and grease from your barbecue. Suitable for use with the 7000 and 2000 series barbecues.



Product Details

FEATURES

Disposable Foil Tray

A disposable foil tray to use when preparing, cooking, plating and storing and cleaning up from barbequing.

BENEFITS

Disposable Convenience

Easily remove collected waste oil and grease from your BBQ



Specifications

ACCESSORIES

PRODUCT PROFILE

Domestic warranty details (yrs) 1

Product Relates to BBQ

Design family Signature

OUTDOOR KITCHENS

PRODUCT PROFILE

Design Family Signature

FEATURES

Accessory Other Features debossed logo

SHIPPING AND STUFFING QUANTITIES

SHIPPING

Shipping Weight (Kg) 012

Pack Dimensions Height (mm) 35

Pack Dimension Width (mm) 410

Pack Dimension Depth (mm) 120

BEEFEATER FILTER TYPE



BEEFEATER FILTER TYPE

BeefEater Filter Type

Cookware and Utensils

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz