

Rotisserie Kit for 4 Burner BBQ



Product Details

FEATURES

Slow and Even Cooking
Transforms your BBQ into a versatile rotisserie oven, allowing you to cook a variety of foods with a slow and even rotation

Adjustable Prongs
Adjustable prongs that securely hold the food in place as it rotates, resulting in uniformly cooked and deliciously succulent dishes

Easy Installation
Designed for easy installation on compatible barbecues to fit into the barbecue's existing setup

Check model compatibility

BENEFITS

Rotisserie Cooking
The BBQ rotisserie kit transforms your BBQ into a versatile rotisserie oven, allowing you to cook a variety of foods with a slow and even rotation. This method ensures juicy, tender meats with a crispy exterior, elevating your barbecuing repertoire to new heights.

Adjustable and Secure
The rotisserie kit features adjustable prongs that securely hold the food in place as it rotates. This ensures stability and prevents any mishaps while maintaining a consistent cooking position, resulting in uniformly cooked and deliciously succulent dishes.

Easy Installation and Clean up
BBQ rotisserie kits are designed for easy installation on compatible barbecues to fit into the barbecue's existing setup. Additionally, clean-up is made simple with removable components, allowing for effortless maintenance and ensuring you can focus on enjoying your perfectly cooked meal.

Specifications

ACCESSORIES

PRODUCT PROFILE

Product Relates to BBQ

Items included 4 burner

FEATURES

Accessory Other Features Stainless steel,durable construction

BEEFEATER FILTER TYPE

BeefEater Filter Type Cookware and Utensils

SPECIFICATIONS

Finish stainless steel

SHIPPING AND STUFFING QUANTITIES

SHIPPING

Shipping Weight (Kg) 2.55

Pack Dimensions Height (mm) 950

Pack Dimension Width (mm) 142

Pack Dimension Depth (mm) 95

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz