

BBQ Fish Turner



Product Details

FEATURES

Secure grip for control and precision	Sturdy construction from stainless steel with heavy duty handle	Multi-purpose for a range of barbecuing jobs	Dishwasher safe for ease of maintenance
Hang with ease convenient hanging hole			

BENEFITS

<p>Gentle Handling</p> <p>The BBQ fish turner is specifically designed to delicately lift and turn delicate fish fillets without causing them to break or fall apart. Its thin and wide blade ensures precise control, allowing you to handle fish with ease.</p>	<p>Sturdy Construction</p> <p>Constructed from durable stainless steel, the BBQ fish turner offers strength and resilience to withstand the heat of the BBQ. Its robust design ensures long-lasting performance, making it a reliable companion for countless BBQ sessions.</p>
<p>Dishwasher Safe</p> <p>Our BBQ tools are hassle-free when it comes to clean up. Simply toss them in the dishwasher, and they'll come out spotless, ready for your next barbecuing session. Enjoy the convenience and ease of maintenance with our dishwasher-safe BBQ tools.</p>	<p>Hang with Ease</p> <p>Our BBQ tools feature a convenient hanging hole, making storage a breeze. Keep your grilling essentials within reach and neatly organised by easily hanging them on hooks or racks. With the built-in hanging hole, your BBQ tools are always ready for action, saving you time and ensuring a clutter-free barbecuing experience.</p>



Specifications

PRODUCT PROFILE

Product Relates to	BBQ
--------------------	-----

FEATURES

Accessory Other Features	Stainless steel,Dishwasher cleanable,Non-stick surface,Durable construction,Easy to clean,Universal,Easy grip
--------------------------	---

DIMENSIONS

Total height (mm)	364
Total width (mm)	75
Total depth (mm)	90

SHIPPING

Shipping Volume (m3)	0.033
Shipping Weight (Kg)	0.4
Pack Dimensions Height (mm)	405
Pack Dimension Width (mm)	106
Pack Dimension Depth (mm)	51

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz