

425L UltimateTaste 500 bottom freezer fridge, dark stainless steel with TasteLockAuto Easy-glide crisper, EvenTemp cooling, Multizone Deli compartment, twist and serve icemaker & TasteGuard deordoriser





# **Product Details**

## **FEATURES**

TasteLock Easy-glide crispers

Energy efficiency
Enjoy a big performance
without a big bill. Our
refrigerators are designed be
energy efficient protecting
the environment and reducing
your power costs.

Mark-resistant real stainless steel finish

FlexStor

FreshPlus Cooling
Keep your ingredients at their
fresh flavourful best. When
the fridge door is open, the
innovative FreshPlus
technology immediately
begins the recooling process
to replace the lost cold air
faster when the door closes.
This ensures better
preservation of farm fresh
food and helps minimise
waste.

Fast Ice function
When adding a large amount
of food to the freezer, simply
use the Fast Ice function,
which decreases the
temperature to -23C for 90
minutes before returning to
the pre-set mode.

Boost mode After a large grocery shop, use the Boost function when adding food to your fridge, so that the temperature decreases for 90 minutes before returning to the pre-set mode. Drinks chill
Use the handy drinks chill
feature to remind yourself
when to take your drinks out
of the freezer.

Crispers on telescopic runners

Enjoy effortless access to all of your food, even items right at the back of the crisper, with easy-slide runners that fully extend.

Multi-function electronic touch controls Ideally located on the inside of the cabinet, you can set the temperature and use functions such as boost mode, fast ice, holiday mode

and drinks chill with just a

touch of a button.

Twist ice and serve With a compact design and two removable ice trays, entertaining is a breeze when you always have ice ready for drinks. Fridge & freezer door alarm An alarm sounds if the door is left open to help keep the interior cool and reduce the risk of spoilage.





Holiday mode Going away? Set the fridge to Holiday Mode to help minimise defrosting and save energy. R600a refrigerant Our fridges use R600a, a non-synthetic refrigerant thats more environmentally friendly than the commonly used R134a. LED Lighting
With our new LED lighting at
both the top and sides of the
fridge, the light-filled interior
illuminates the content of
your fridge so you can find
anything you need quickly
and easily.

Frost free
Save your precious time with
a freezer that doesn't ice up
and need manual defrosting.

FreshSense deodoriser
The in-built Fresh Sense
deodoriser freshens the air
and absorbs strong odours
like seafood and cheese, to
keep your fridge smelling
clean and fresh.

### **BENEFITS**

Understanding new capacity and energy ratings
From the 15th August 2021, the way refrigerators are tested to
calculate Energy Star Ratings and energy consumption have
changed. This means that the capacity and energy rating
calculations have changed, however the product remains
unchanged. Be sure to check all new ratings to ensure that
your comparisons are consistent with the new standards.

#### Fresh is best

Our innovative TasteLock crispers automatically control the humidity levels to keep your fruit and vegetables at their best for longer. While Easy-glide crisper drawers open effortlessly, even when they're full.

#### Power saver

Enjoy better performance without a big bill. Our refrigerators are designed to be energy efficient to help reduce your power costs.

#### Stylish and smart

High quality, mark-resistant real stainless steel, now available in a new chic dark hue or classic natural stainless steel, lends a touch of class to any kitchen. Inside, the generous interior marries innovation and style in equal measure.

#### Designed just for you

Customise your fridge just the way you want it. FlexStor™ makes it simple to arrange the fridge to your needs with adjustable door bins and shelves. Different sized compartments effortlessly accommodate items big or small.

#### Keep it cool

The fridge door is one of the most opened in any household, which is why we came up with FreshPlus technology to help maintain the perfect temperature inside your fridge. It automatically detects when it needs to begin cooling, keeping the temperature down to lock the freshness in.





Increase the chill

With a combination of Fast Ice and Boost mode you will always be prepared when entertaining. After a large shop, Boost Mode increases the chill rate of the refrigerator for 90 minutes whilst the Fast Ice function lowers the freezer to -23C for 12 hours, before returning to their pre-set temperatures, to ensure your produce stays fresher longer.

#### Effortless access

It is one of the most hardworking appliances in your house, so it makes sense your fridge takes the effort out of simple tasks. Our smooth telescopic runners ensure you can reach the very back of the crisper and freezer drawers easily.



# **Specifications**

## PRODUCT PROFILE

Domestic warranty details (yrs)	2
Additional domestic warranty for the sealed refrigeration system only (yrs)	3
Refrigerator Type	bottom mount
Exterior door finish	dark stainless steel
Handle design	bar handle
Fridge door opening	left or right
Cooling system	frost free
Refrigerant	R600a

## **DIMENSIONS**

Total height (mm)	1725
Cabinet height (mm)	1705
Total width (mm)	699
Cabinet width (mm)	693
Total depth (mm)	773
Cabinet depth (mm)	641
Depth door open 90degree (mm)	1360
Air space above cabinet (mm)	50
Food Compartment Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	300
Freezer Compartment Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	125
Total Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	425



## **DIMENSIONS**

Food compartment capacity (gross in litres)	311
Freezer compartment capacity (gross in litres)	142
Total Gross Capacity (L)	453
Food compartment capacity (net in litres)	297
Total Net Capacity (L)	419

## **ENERGY**

Energy Star Rating - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	4.5
Energy Consumption (kWh/year) - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	291
Energy Star Rating AS/NZS 4474.2:2009	4.5
Energy consumption AS/NZS 4474.2:2009 (kWhr/yr)	297

## **REFRIGERATOR SYSTEM**

Controls	electronic (with display)
Controls location	internal
Controls type	touch
Control functions	drink chill alarm,freezer temp alarm,holiday mode,eco mode,fast ice function,boost mode
Door alarm	fridge

## FOOD COMPARTMENT

## **SHELVING**



DELI-COMPARTME	NT	Shelf material	glass
Deli-Compartment Runr system	ner telescopic		
Full width compartment	1		
CRISPERS		LIGHTING	
Crisper lid/shelf	glass	Main light	LED
Crispers Runner system	telescopic		
Full width crisper	1		
Crisper features	humidity controlled,automatic humidity control,fully sealed		
OTHER PROPERT	IES	FOOD COMPARTM	MENT DOOR
Other Properties-FOOD COMPARTMENT	Deodoriser,Shelf bottle rack,Egg tray	BINS	
		Deep bottle bin	1
		Shallow bin	1
DAIRY COMPARTM	ENT	FREEZER COMPA	ARTMENT
Half width, with lid	1	ICE FACILITY	





Twist ice and serve 2

# BASKET/DRAWER


Full width plastic basket	2
Basket/Drawer runner system	telescopic

# OTHER PROPERTIES

Half width shallow freezer 1 drawer



# **Dimensions**



## Minimum Recommended Airspaces

If you have a cupboard above the refrigerator with a rear gap of less than 100mm (Y), recommended minimum clearance at the top of the refigerator increases from 30mm to 70mm (X).

**Please note:** Doors are designed to sit proud of cabinetry (not flush).

When positioned in a corner area, spacing of at least 400mm on the hinge side will allow the doors to open enough to enable the removal of bins and shelves.

Bottom Mount Models	Door width (W)	Total depth (D)	Maximum height (H)	Cabinet width (W1)	Cabinet depth (D1)	Depth door open (D2)
EBE5367SB, EBE5307BB, EBE5307SB	796	773	1725	790	641	1457
EBE4507BB, EBE4507SB	699	773	1725	693	641	1360

front corner edge of cabinet.

For connection kit installation instructions go to electrolux.com.au

Important! Please ensure that the access to your kitchen (including doorways, corridors, island benches, etc) allows sufficient clearance to move your fridge into position.

Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions.



# **Terms and Conditions**

#### **IMPORTANT**

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

#### PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

#### WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

#### **ELECTROLUX HOME PRODUCTS AUSTRALIA**

telephone: 1300 363 640 fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

**ELECTROLUX HOME PRODUCTS NEW ZEALAND** 

telephone: 09 573 2230 fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz