

A 6kg capacity clothes dryer, with silver door and control panel, with electronic sensor push button controls, reversing action, stainless steel drum, child lock and crease free options



Product Details

FEATURES

Delay start The wash programme may be started after a designated amount of time	Child lock The child lock can be turned on to prevent children tampering with the electronic controls.	Automatic temperature limit	Directional front vent grill
Remote element rear location	Safety thermostat heater	Crease free option	Clean lint filter reminder LED
Fabric type selection delicate / normal	New wave lifters rotate clothes more efficiently	Auto-sensing	Reversing tumble action
Wall mount option	Drying system - exhaust venting	Reversible control panel	Optional end of cycle buzzer

BENEFITS

Crease-free Periodically rotates the drum after the drying cycle has finished. Prevents clothes from settling, which reduces the need for ironing	Protects your clothes Senses the residual moisture in the clothes and automatically stops when the desired 'dryness' is achieved
Wave Lifters Turns the laundry more effectively in the drum ensuring more even drying results and less creasing	6kg capacity Save time, drying 20% more clothes than a 5kg dryer

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
---------------------------------	---

Dryer Type	exhaust venting front/rear
------------	----------------------------

Capacity (Kg)	6
---------------	---

Wall mount option	supplied with unit
-------------------	--------------------

ENERGY

Energy Efficiency Star Rating	2
-------------------------------	---

Energy Consumption (KWhr/yr)	267
------------------------------	-----

DIMENSIONS

Total height (mm)	800
-------------------	-----

Total width (mm)	600
------------------	-----

Total depth (mm)	600
------------------	-----

CONTROLS

Type of controls	electronic
------------------	------------

Options available	delicates setting,heat settings,crease free option,delay start,auto sensing,Reversible control panel,safety thermostat heater,buzzer
-------------------	--

Type of display	LED
-----------------	-----

Fabric type selection	delicate,normal
-----------------------	-----------------

BUTTON FUNCTIONS

DRYING PROGRAMS

BUTTON FUNCTIONS

Reminder/Indicators clean lint filter reminder,time to program start,child safety lock door,drying,cooling,end/Anticrease,delicate,buzzer,start time/program duration

Functions power/on/off,program 30min,program 60min,program 90min,Start/Pause,normal,delicate,airing,clean filter reminder,Child Lock,buzzer,Delay Start

DRYING PROGRAMS

Drying Programs timed programs,auto sensing,Delicate

Degree of dryness extra,normal,iron dry

Venting optional rear venting,directional front vent grille

DRUM

Spin tub material stainless steel

DOOR

Type glass insert

Dryer Door colour window

Door diameter 424

Door angle opening 168

Door safety child lock

CABINET

Cabinet Colour white

Cabinet material painted galvanized steel

TECHNICAL

Service cord length 180

Dryer Lint filter position front pocket

Buzzer end of cycle

TECHNICAL

Dryer Drying time for standard load	161
-------------------------------------	-----

Dryer Element watts	2250
---------------------	------

Dryer Safety thermostat heater	No
--------------------------------	----

Noise level dBA	63
-----------------	----

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz