

Electrolux 800 Series with Clean Station





Product Details

FEATURES

Multi-function emptying station
Maximize efficiency with extra battery charging, tool storage, and cleaning hose for maintenance.

Extra Battery Runtime
180min
Vacuum more in one charge.
Up to 100 minutes of
continuous cleaning using the
complete unit and up to 180
minutes using the hand unit.
Disclaimer: Internal tests
according to IEC 62885-4 on
min mode and fully charged.

Multiple cyclone Longer performance, less filter maintenance Fast, Easy access Grab & Go function for quick, efficient clean-ups.

Multi-surface nozzle PowerPro Multi-surface Nozzle thoroughly cleans all floor types, and picks up dust in crevices.

BENEFITS

FAST, EASY ACCESS

The quick release Grab & Go function lets you grab the handheld unit from its charging station for fast, efficient clean-ups, with no assembly required. The Roll in Roll out function lets you roll the vacuum in and out of the magnetic charging station for smooth, easy access.



Specifications

MAIN

Electrolux
Battery Instant
900402322
7333394038643
EFP81825SB
-
800 Cordless Cleaner + Clean Station
Bagless
Bagged
2 years

DESIGN

Main colour	Shell White

CONTROLS

Electronics	Auto & +/- Hand operated
Control position	Handle

TECHNICAL SPECIFICATIONS

Volt (V)	25.2
Battery cell, type	Li-ION



CONTROLS

Filter indicator	Yes
Standby lamp	Yes

ACCESSORIES / NOZZLE

Accessories	Yes
Small brush	Yes
Crevice tool	Yes

PACKAGING & LOGISTICS

SINGLE PACKAGE	
Gross weight (kg)	18.25
Package width (mm)	350
Package depth (mm)	780
Package height (mm)	460
Max units in 20 ft cont.	196
Max units in 40 ft cont.	450
Max units in 20 HC ft cont.	225



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This appliance is warranted against manufacturing defects in Australia and New Zealand for 24 months following the date of original purchase of the Appliance, where the Appliance is used for personal, domestic or household use (i.e. normal single family use) as set out in the instruction manual. Where the Appliance and accessories (including nozzles, brushes or other cleaning attachments) are used for commercial purposes, the Appliance will then be warranted against manufacturing defects in Australia for 3 months and in New Zealand for 3 months, following the date of original purchase of the Appliance.

ELECTROLUX FLOOR CARE & SMALL APPLIANCES AUSTRALIA

telephone: 1300 366 366 fax: 1800 673 326

email: info@electrolux.com.au web: www.electrolux.com.au

ELECTROLUX FLOOR CARE & SMALL APPLIANCES NEW ZEALAND

telephone: 05 08 730 730

fax: 09 573 2382

email: floor.care@electrolux.co.nz

web: www.electrolux.co.nz