
70cm Induction Cooktop



Product Details

FEATURES

Four large induction zones
Four large induction zones

Electronic controls with LED display and acoustic signal
Electronic controls with LED display and acoustic signal

Booster function on all zones
Booster function on all zones

Residual heat indicators all zones
Indicates which area is too hot to comfortably touch.

BENEFITS

Maxisense cook tops offer the ultimate in cooking flexibility
Maxisense cook tops offer the ultimate in cooking flexibility, allowing the consumer to break free from the marked pot zones on traditional cook top surfaces

Maximum flexibility
Maxisense induction cooktops are developed with three or four extra large zones, which detect pan presence and location and are not restricted to traditional circular zones

Sleek & stylish design
With beveled edges and black ceramic glass, Maxisense hobs integrate seamlessly into any modern kitchen

Extra safe
Maxisense cooktops combine the traditional safety of induction cooking, including the 'cool touch surface', with a variety of safety features such as child lock, residual heat indicators and auto switch-off

Specifications

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640
fax: 1800 350 067
email: customercare@electrolux.com.au
web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230
fax: 09 573 2221
email: customercare@electrolux.co.nz
web: www.electrolux.co.nz