


78cm Induction Cooktop



## Product Details

### FEATURES

---

Residual heat indicator Indicates which area is too hot to comfortably touch. Remains on if ceramic surface is above 40c	Timer	Minute minder	Auto warm-up function
---	-------	---------------	-----------------------

---

STOP + GO function	Touch and slide controls Touch the control bar at the necessary heat setting	9 heat settings + Boost on all zones	Child safety device
--------------------	---	--------------------------------------	---------------------

---

Acoustic signal Confirms use of the control panel	4 Induction Zones incl a 28cm Zone
--	------------------------------------

---

### BENEFITS

---

**Sleek & stylish design**  
With beveled edges and black ceramic glass, Maxisense hobs integrate seamlessly into any modern kitchen

**Ultimate in safety and comfort**  
Induction cooking generates heat in the cookware, so surfaces around the pot are cool to touch, and the cooking environment remains cooler. The surface is also easy to clean, as spills are simply wiped away

**Create like a professional**  
Induction combines the speed of gas with the addition of precise control. A range of cooking zones allow the cook to prepare any sized meal faster with a more consistently high quality

**Touch and slide temperature control**  
The Induction cooktop is easy to use and intuitive with a touch and slide control. Simply slide your finger along the glass surface to change cooking temperature instantly

---

## Specifications

### PRODUCT PROFILE

---

Domestic warranty details (yrs)	2
Cooktop type	full induction
Materials/Colour	black

---

### CONTROLS

---

Controls of Cooktops	slide touch pad
Functions of Cooktops	stop and go,automatic warm up,timer,Keep warm function,cooking timer with acoustic signal,booster
Indicators/display	fault indicator,residual heat warning lamps
Features of Cooktop	safety cut off,electronic timer,9 stage digital power level display for each cooki,safety child lock,hot surface indicator,sound off
Timer of Cooktop	programmable 99min

---

### DIMENSIONS

---

Total product height (mm)	55
Total product width (mm)	780
Total product depth (mm)	520
Cut out width (mm)	750
Cut out depth (mm)	490

---

### ELEMENTS/BURNERS

---

#### LEFT FRONT ZONE

---

Left front zone	induction
Left front Watts	1800
Left front boost watts	2500
Left front diameter mm	180

---

**LEFT REAR ZONE**

---

Left rear zone	induction
Left rear watts	1800
Left rear diameter mm	180

---

**RIGHT REAR ZONE**

---

Right rear zone	induction
Right rear watts	2400
Right rear diameter mm	280

---

**RIGHT FRONT ZONE**

---

Right front zone	induction
Right front Watts	1400
Right front diameter mm	145

---

**ELECTRICAL SPECIFICATIONS**

---

Connected load KW	7.4
Type of connection	hardwired

---

## Terms and Conditions

### IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

### PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

### WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

#### ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: [customercare@electrolux.com.au](mailto:customercare@electrolux.com.au)

web: [www.electrolux.com.au](http://www.electrolux.com.au)

#### ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: [customercare@electrolux.co.nz](mailto:customercare@electrolux.co.nz)

web: [www.electrolux.co.nz](http://www.electrolux.co.nz)