

90cm 5 zone induction cooktop with FlexiBridge, Chef Mode, MaxiZone, 14 stage slide controls and Hob2Hood capability.





Product Details

FEATURES

Flexibility to cook with FlexiBridge	Chef Mode	MaxiZone	Hob2Hood technology
Touch and slide controls Touch the control bar at the necessary heat setting	STOP + GO function	Timer and minute minder	Auto warm-up function
Auto pot detection			

BENEFITS

Your kitchen, your way

Enjoy a kitchen appliance thats versatile enough to handle your most complex dishes. Thanks to FlexiBridge, you can combine your induction segments in a range of ways or use them all at once for the largest single cooking area available. Perfect heat distribution ensures even cooking all the way through.

Cook like a chef

Chef Mode enables you to choose between different preset heated zones by simply sliding your pan across the hob. Go from boiling to simmering to keeping the pot warm by placing it on the different heat zones allowing you full control in the kitchen.

Enjoy the space and freedom to cook what you want Use large pots and pans like a professional chef. The extra large MaxiZone on this hob gives you the freedom to effortlessly prepare all kinds of dishes that need a large pan with consistent heat, like that delicious paella youve been wanting to cook.

The hands free hood

When paired with a compatible Electrolux extractor hood, the Hob2Hood automatically switches it on as you start cooking and adjusts the fan speed based on how you are using your hob. This means you can boil, sear or stir-fry without having to touch your hood with greasy fingers.





Control at your fingertips

The touch controls on this hob lets you heat up, down or switch off immediately. Just gently slide your finger across the control to the temperature you need and you can be confident it will respond right away, so you can create delicious meals effortlessly. The Stop & Go feature offers a useful keep warm setting if youre unexpectedly interrupted.



Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Cooktop type	induction
Materials/Colour	black ceramic glass

DIMENSIONS

Total product height (mm)	55
Total product width (mm)	910
Total product depth (mm)	520
Cut out width (mm)	880
Cut out depth (mm)	490

CONTROLS

Controls of Cooktops	Touch and Slide controls
Position of controls	front
Functions of Cooktops	stop and go,automatic warm up,timer,Keep warm function,cooking timer with acoustic signal,automatic switch off,power booster,Hob2Hood,FlexiBridge,Chef Mode
Indicators/display	fault indicator,3 level residual heat indicator

ELEMENTS/BURNERS

LEFT FRONT ZONE

Left front zone	induction extended
Left front Watts	2300
Left front boost watts	3400
Left front diameter mm	215



CONTROLS

Features of Cooktop

safety cut off,overheating protection,electronic timer,minute

minder, hot surface

indicator,FlexiBridge zone,Chef Mode,function lock,auto pot sensors,child safety device lock,Hob2Hood Connectivity

Timer of Cooktop

programmable 99min,auto

off,countdown

LEFT REAR ZONE

Left rear zone	induction extended
Left rear watts	2300
Left rear diameter mm	215

CENTRE FRONT ZONE

Centre front zone	induction maxi
Centre front Watts	3500
Centre front diameter mm	280

RIGHT FRONT ZONE

Right front zone	induction
Right front Watts	1400
Right front diameter mm	145

RIGHT REAR ZONE

Right rear zone	induction
Right rear watts	1800
Right rear diameter mm	180

ELECTRICAL SPECIFICATIONS

SHIPPING



ELECTRICAL SPECIFICATIONS

Connected load KW	11
Maximum current rating (amps)	45
Type of connection	hardwired

SHIPPING


Shipping Volume (m3)	0.93
Shipping Weight (Kg)	20.0
Pack Dimensions Height (mm)	125
Pack Dimension Width (mm)	635
Pack Dimension Depth (mm)	1170
Total shelf area (m^2)	74.30

STUFFING QUANTITIES

20ft	128
40ft	288
40ft HC	342



Dimensions



^{*}Unless otherwise specified in rangehood installation details.



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230 fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz