

A double, electric multifunction oven with a stainless steel finish and rotary push in / push out controls.



Product Details

FEATURES

Defrost option

Fan assisted defrosting which speeds up the defrosting process, compared with defrosting food in the refrigerator. Won't accidentally pre-cook food.

Concealed bottom element

The concealed bottom element provides professional finish to pastry bases and allows for easy cleaning.

Booster Function

Provides faster than normal heat-up, can be activated or de-activated at anytime. Keeps oil temperature when adding foods, operates for maximum 10 minutes. Booster element is either 800 watt or 500 watt depending on element size.

Pizza Function

The rear and base element plus the fan operates to ensure a crisp pizza base and a moist topping every time.

Closed door grilling

yes

Specifications

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz