

A 501L frost free single door refrigerator with best in class energy efficiency, FreshZone™ double insulated crisper, water dispenser & mark resistant stainless steel.



Product Details

FEATURES

Best in class water

Staying hydrated is simple when you have fresh filtered water at your fingertips. With our class-leading through-door water dispenser, entertaining has never been easier.

FreshPlus Cooling

Keep your ingredients at their fresh flavourful best. When the fridge door is open, the innovative FreshPlus technology immediately begins the recooling process to replace the lost cold air faster when the door closes. This ensures better preservation of farm fresh food and helps minimise waste.

FlexStor

FreshZone™ Double Insulated Crispers

Designed to maximise food preservation for fresher, better tasting food, the double insulated crispers increase temperature stability and humidity levels in the crisper.

Mark resistant, high quality stainless steel

The invisible, mark-resistant coating is easy to clean and helps protect the fridge exterior from fingerprints and grime.

Crisper divider

Now you can adapt your crisper to the size and shape of your farm fresh product. Offering ideal storage conditions, the moveable crisper divider allows you to split the contents so you can store your fruit and vegetables separately.

Holiday mode

Going away? Set the fridge to Holiday Mode to help minimise defrosting and save energy.

Boost mode

After a large grocery shop, use the Boost function when adding food to your fridge, so that the temperature decreases for 90 minutes before returning to the pre-set mode.

Door alarm

An alarm sounds if the door is left open to help keep the interior cool and reduce the risk of spoilage.

Multi-flow air delivery

The intelligent airflow system evenly disperses air to ensure optimum temperatures so your food is kept fresher for longer.

Multi-function electronic touch controls

Ideally located on the inside of the cabinet, you can set the temperature and use functions such as boost mode, fast ice, holiday mode and drinks chill with just a touch of a button.

Frost free

Save your precious time with a freezer that doesn't ice up and need manual defrosting.

R600a refrigerant

Our fridges use R600a, a non-synthetic refrigerant that's more environmentally friendly than the commonly used R134a.

FreshSense deodoriser

The in-built Fresh Sense deodoriser freshens the air and absorbs strong odours like seafood and cheese, to keep your fridge smelling clean and fresh.

Wine Caddy

Stylish, functional and space efficient, the steel bottle caddy can easily and safely store up to six large bottles.

LED Lighting

With our new LED lighting at both the top and sides of the fridge, the light-filled interior illuminates the content of your fridge so you can find anything you need quickly and easily.

MultiZone Deli compartment

Designed to isolate odours and seal in freshness, discover the perfect place to store your artisan cheeses, cured meats and deli items safely away from other ingredients.

Non-slip grips

The easy-clean dishwasher-safe door compartment grips look great and also help protect bottles and jars from moving around.

Crispers on telescopic runners

Enjoy effortless access to all of your food, even items right at the back of the crisper, with easy-slide runners that fully extend.

Capacity

With even more useable interior space, you can store and organise your food with ease.

Drinks chill

Use the handy drinks chill feature to remind yourself when to take your drinks out of the freezer.

BENEFITS**Maximise food freshness**

The fresher the food is, the more delicious the taste. By increasing the stability of temperature and humidity levels in the double insulated crisper, food preservation is maximised. And that means better tasting farm fresh ingredients for all of your favourite dishes.

The FreshPlus™ advantage

Did you know that your fridge door is one of the most opened doors in your home? That's why we created our innovative FreshPlus™ technology. Designed to maintain the perfect temperature and detect when the fridge door opens, it immediately begins re-cooling to replace cold air for fresher, longer lasting, great tasting food.

Superior styling

With sleek styling, generous interior space, high-quality mark-resistant stainless steel, and LED lighting, Electrolux FreshPlus™ refrigerators bring the utmost style to your kitchen.

Continuous filtered water

Now you can enjoy continuous cool filtered water at the touch of a button. The innovative water tubing is integrated at the top of the fridge to maximise interior space, while the ultra-slim water dispenser ensures you can effortlessly enjoy refreshment whenever you need it.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Additional domestic warranty for the sealed refrigeration system only (yrs)	3
Refrigerator Type	vertical fridge
Exterior door finish	Stainless steel
Handle design	bar handle
Fridge door opening	right
Cooling system	frost free
Refrigerant	R600a
Dispenser type	water
Plumbed water supply required	Yes

DIMENSIONS

Total height (mm)	1725
Cabinet height (mm)	1705
Total width (mm)	699
Cabinet width (mm)	693
Total depth (mm)	773
Cabinet depth (mm)	640
Depth door open 90degree (mm)	1360
Food compartment capacity (gross in litres)	501
Total Gross Capacity (L)	501
Food compartment capacity (net in litres)	460
Total Net Capacity (L)	460

ENERGY

REFRIGERATOR SYSTEM

ENERGY

Energy Star Rating AS/NZS 4474.2:2009 3.5

Energy consumption AS/NZS 4474.2:2009 (kWhr/yr) 259

FOOD COMPARTMENT

DELI-COMPARTMENT

Deli-Compartment Runner system telescopic

Full width compartment 1

CRISPERS

Crisper lid/shelf glass

Crispers Runner system telescopic

Full width crisper 1

REFRIGERATOR SYSTEM

Controls electronic (with display)

Controls location internal

Controls type touch

Control functions drink chill alarm, holiday mode, eco mode, boost mode

Door alarm fridge

SHELVING

Shelf material glass

LIGHTING

Main light LED

OTHER PROPERTIES

Other Properties-FOOD COMPARTMENT	Deodoriser, Water filter, Steel wine caddy
--------------------------------------	---

DAIRY COMPARTMENT

Half width, with lid	2
----------------------	---

FOOD COMPARTMENT DOOR

BINS

Deep bottle bin	2
-----------------	---



Shallow bin	1
-------------	---

Non-slip grip mats	Yes
--------------------	-----


EXTERNAL

Dispenser through door	water
------------------------	-------


Dimensions



Minimum Recommended Airspaces



Joined dimensions



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz