

**466L UltimateTaste 500 single door fridge, stainless steel**



## Product Details

### FEATURES

---

<p><b>TasteLock Easy-glide crispers</b></p>	<p><b>Energy efficiency</b> Enjoy a big performance without a big bill. Our refrigerators are designed be energy efficient protecting the environment and reducing your power costs.</p>	<p><b>Mark-resistant real stainless steel finish</b></p>	<p><b>Filtered water</b></p>
<p><b>FlexStor</b></p>	<p><b>FreshPlus Cooling</b> Keep your food at its best with our innovative FreshPlus technology. Whenever the fridge door is open, it immediately begins recooling to replace the lost cold air.</p>	<p><b>MultiZone Deli compartment</b> Designed to isolate odours and seal in freshness, discover the perfect place to store your artisan cheeses, cured meats and deli items safely away from other ingredients.</p>	<p><b>Boost mode</b> After a large grocery shop, use the Boost function when adding food to your fridge, so that the temperature decreases for 90 minutes before returning to the pre-set mode.</p>
<p><b>Crispers on telescopic runners</b> Enjoy effortless access to all of your food, even items right at the back of the crisper, with easy-slide runners that fully extend.</p>	<p><b>Multi-function electronic touch controls</b> Ideally located on the inside of the cabinet, you can set the temperature and use functions such as boost mode, fast ice, holiday mode and drinks chill with just a touch of a button.</p>	<p><b>Holiday mode</b> Going away? Set the fridge to Holiday Mode to help minimise defrosting and save energy.</p>	<p><b>Door alarm</b> An alarm sounds if the door is left open to help keep the interior cool and reduce the risk of spoilage.</p>
<p><b>LED Lighting</b> With our new LED lighting at both the top and sides of the fridge, the light-filled interior illuminates the content of your fridge so you can find anything you need quickly and easily.</p>	<p><b>R600a refrigerant</b> Our fridges use R600a, a non-synthetic refrigerant thats more environmentally friendly than the commonly used R134a.</p>	<p><b>FreshSense deodoriser</b> The in-built Fresh Sense deodoriser freshens the air and absorbs strong odours like seafood and cheese, to keep your fridge smelling clean and fresh.</p>	<p><b>Frost free</b> Save your precious time with a freezer that doesn't ice up and need manual defrosting.</p>

## BENEFITS

---

### Understanding new capacity and energy ratings

From the 15th August 2021, the way refrigerators are tested to calculate Energy Star Ratings and energy consumption have changed. This means that the capacity and energy rating calculations have changed, however the product remains unchanged. Be sure to check all new ratings to ensure that your comparisons are consistent with the new standards.

### Fresh is best

Our innovative TasteLock crispers automatically control the humidity levels to keep your fruit and vegetables at their best for longer. While Easy-glide crisper drawers open effortlessly, even when they're full.

---

### Power saver

Enjoy better performance without a big bill. Our refrigerators are designed to be energy efficient to help reduce your power costs.

### Stylish and smart

High quality, mark-resistant real stainless steel lends a touch of class to any kitchen. Inside, the generous interior marries innovation and style in equal measure.

---

### Pour a glass

Like a cool glass of pure, filtered water? Your fridge is there to deliver, any time of the day or night at the touch of a button.

### Designed just for you

Customise your fridge just the way you want it. FlexStor™ makes it simple to arrange the fridge to your needs with adjustable door bins and shelves. Different sized compartments effortlessly accommodate items big or small.

---

### Keep it cool

The fridge door is one of the most opened in any household, which is why we came up with FreshPlus technology to help maintain the perfect temperature inside your fridge. It automatically detects when it needs to begin cooling, keeping the temperature down to lock the freshness in.

### Deli delights

The MultiZone deli compartment lets you indulge in your favourite artisan cheeses and deli delights without leaking odours into other food items.

---

### Increase the chill

Always be prepared when entertaining with Boost mode. After a large shop, Boost Mode increases the chill rate of the refrigerator for 90 minutes before returning to the pre-set temperature, to ensure your produce stays fresher longer.

### Effortless access

It is one of the most hardworking appliances in your house, so it makes sense your fridge takes the effort out of simple tasks. Our smooth telescopic runners ensure you can reach the very back of the crisper drawers easily.

---

## Specifications

### PRODUCT PROFILE

Domestic warranty details (yrs)	2
Additional domestic warranty for the sealed refrigeration system only (yrs)	3
Refrigerator Type	vertical fridge
Exterior door finish	Stainless steel
Handle design	bar handle
Fridge door opening	right
Cooling system	frost free
Refrigerant	R600a
Plumbed water supply required	Yes

### DIMENSIONS

Total height (mm)	1725
Cabinet height (mm)	1705
Total width (mm)	699
Cabinet width (mm)	693
Total depth (mm)	773
Cabinet depth (mm)	640
Depth door open 90degree (mm)	1360
Food Compartment Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552-2015) *	466
Total Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552-2015) *	466
Food compartment capacity (gross in litres)	501
Total Gross Capacity (L)	501
Food compartment capacity (net in litres)	460

## ENERGY

---

Energy Star Rating - AS/NZS 4474.1 2007 (IEC 62552- 2015) \* 3.5

---

Energy Consumption (kWh/year) - AS/NZS 4474.1 2007 (IEC 62552- 2015) \* 216

---

Energy Star Rating AS/NZS 4474.2:2009 3.5

---

Energy consumption AS/NZS 4474.2:2009 (kWhr/yr) 259

---

## FOOD COMPARTMENT

---

### DELI-COMPARTMENT

---

Deli-Compartment Runner system telescopic

---

Full width compartment 1

---

## CRISPERS

---

## DIMENSIONS

---

Total Net Capacity (L) 460

---

## REFRIGERATOR SYSTEM

---

Controls electronic (with display)

---

Controls location internal

---

Controls type touch

---

Control functions drink chill alarm, holiday mode, eco mode, boost mode

---

Door alarm fridge

---

## SHELVING

---

Shelf material glass

---

## LIGHTING

---

Crisper lid/shelf	glass
-------------------	-------

---

Crispers Runner system	telescopic
------------------------	------------

---

Full width crisper	2
--------------------	---

---

Crisper features	automatic humidity control,fully sealed
------------------	---

---

Main light	LED
------------	-----

---

## OTHER PROPERTIES

---

Other Properties-FOOD COMPARTMENT	Deodoriser,Water filter,Shelf bottle rack,Egg tray
-----------------------------------	--

---

## DAIRY COMPARTMENT

---

Half width, with lid	1
----------------------	---

---

## FOOD COMPARTMENT DOOR

---

### BINS

---

Deep bottle bin	2
-----------------	---

---

Shallow bin	1
-------------	---

---


## EXTERNAL

---


Dispenser through door	water
------------------------	-------

---


## Dimensions




### Minimum Recommended Airspaces



If you have a cupboard above the refrigerator with a rear gap of less than 100mm (Y), recommended minimum clearance at the top of the refrigerator increases from 50mm to 70mm (X).



**Please note:** Doors are designed to sit proud of cabinetry (not flush).



Front face of bench aligned to front corner edge of cabinet.

When positioned in a corner area, spacing of at least 350mm on the hinge side will allow the doors to open enough to enable the removal of bins and shelves.

Dimensions	Product Height	Product Width	Product Depth	Product Depth (Door Open)	Airspace	Side - both	Top	Behind
ERE5047SC	1725	699	773	1360	ERE5047SC	30	50	50
EFE4227SC	1725	699	773	1360	EFE4227SC	30	50	50

For connection kit installation instructions go to [electrolux.com.au](http://electrolux.com.au)

**Important!** Please ensure that the access to your kitchen (including doorways, corridors, island benches, etc) allows sufficient clearance to move your fridge into position.

**Please note!** Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions.

© 2021 Electrolux Home Products Pty Ltd. E\_DIM\_ERE5047SC\_EFE4227SC\_Sep21

## Terms and Conditions

### IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

### PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

### WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

#### ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: [customercare@electrolux.com.au](mailto:customercare@electrolux.com.au)

web: [www.electrolux.com.au](http://www.electrolux.com.au)

#### ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: [customercare@electrolux.co.nz](mailto:customercare@electrolux.co.nz)

web: [www.electrolux.co.nz](http://www.electrolux.co.nz)