

ERM3707SA Free-standing Fridge



Product Details

FEATURES

Egg tray	Wine rack	Humidity controlled crisper(s)	Full-width can bin
Mark-resistant stainless steel	Frost-free With the Electrolux frost free system, there's no more ice build up in your fridge or freezer, eliminating the need for defrosting.	Multi-flow air delivery With an intelligent airflow system that evenly disperses air to ensure optimum temperatures, your food will be kept fresher for longer.	Rotary Temperature control Convenient and easy to use.
Slideable deli compartment Protects your more delicate items.	Full-width dairy compartment with lid Provides plenty of storage for your dairy items, and keeps them at the optimum temperature	Modular design Inspired for a sophisticated, professional look.	Square lines and hidden hinges. Enjoy the visual harmony of the E:Line collection, with aesthetically designed flat panel doors, squared off edges and fully concealed hinges.
Full length designer bar handles Adds style and elegance to your kitchen.	FreshLogic® deodoriser	Full-width crisper Provides plenty of storage for your fruit and vegetables	Interior light

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs) 2

Refrigerator Type vertical fridge

Exterior door finish Stainless steel

Fridge door opening right

Cooling system frost free

Refrigerant R600a

FOOD COMPARTMENT

SHELVING

Shelf material glass

DIMENSIONS

Total height (mm) 1720

Total width (mm) 595

Total depth (mm) 647

Food compartment capacity (gross in litres) 370

Total Gross Capacity (L) 370

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz