

**Robotic Side Brush Kit for UltimateHome 300 Robotic Vacuum + Mop**



## Product Details

### FEATURES

---

Gets deep into crevices and corners

Suitable for all floor types

Extra soft bristles for delicate floors

Easy click in and out

### BENEFITS

---

#### SIDE BRUSH CLEANS IN CREVICES

The Robotic Side Brush reaches into crevices and collects dust to ensure a deep and thorough clean.

#### DESIGNED FOR ALL FLOOR TYPES

With its extra soft bristles, the side brush is gentle on all floor types while working hard to remove dust and dirt for an exceptional, deep clean.

#### QUICK CLICK ATTACHMENT

The side brush has a simple click-in, click-out fastening function that makes its removal and replacement a snap.

---

## Specifications

### PRODUCT PROFILE

---

Product Relates to	Vacuum
--------------------	--------

---

### FEATURES

---

Accessory Other Features	Quick & easy installation,Durable construction,Easy to clean,Model specific - check for compatibility
--------------------------	---

---

### SHIPPING

---

Shipping Weight (Kg)	0.11
----------------------	------

---

Pack Dimensions Height (mm)	140
-----------------------------	-----

---

Pack Dimension Width (mm)	178
---------------------------	-----

---

Pack Dimension Depth (mm)	57
---------------------------	----

---

## Terms and Conditions

### IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

### PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

### WARRANTY

This appliance is warranted against manufacturing defects in Australia and New Zealand for 24 months following the date of original purchase of the Appliance, where the Appliance is used for personal, domestic or household use (i.e. normal single family use) as set out in the instruction manual. Where the Appliance and accessories (including nozzles, brushes or other cleaning attachments) are used for commercial purposes, the Appliance will then be warranted against manufacturing defects in Australia for 3 months and in New Zealand for 3 months, following the date of original purchase of the Appliance.

#### ELECTROLUX FLOOR CARE & SMALL APPLIANCES AUSTRALIA

telephone: 1300 366 366

fax: 1800 673 326

email: [info@electrolux.com.au](mailto:info@electrolux.com.au)

web: [www.electrolux.com.au](http://www.electrolux.com.au)

#### ELECTROLUX FLOOR CARE & SMALL APPLIANCES NEW ZEALAND

telephone: 05 08 730 730

fax: 09 573 2382

email: [floor.care@electrolux.co.nz](mailto:floor.care@electrolux.co.nz)

web: [www.electrolux.co.nz](http://www.electrolux.co.nz)