Commercial Exclusive: 60cm UltimateCare 500 freestanding dishwasher with 13 place settings, 5 wash programs including Eco Program, AutoFlex and ExtraHygiene, adjustable upper basket, delay start and TemperatureDry system.



Product Details

FEATURES

ExtraHygiene
The ExtraHygiene function gives you maximum cleaning performance with hygienic care.

Eco program
Eco program is water and energy efficient.

AutoFlex
AutoFlex adjusts the wash cycle to each load.

Adjustable upper basket
Adjustable upper basket makes room for more.

Delay start 9-hours
Delay start of the program to suit your schedule.

TemperatureDry
TemperatureDry delivers dry dishes.

BENEFITS

CLEAN WITH EXTRA HYGIENE
The ExtraHygiene function gives you maximum cleaning performance with hygienic care. With the ExtraHygiene function, the final rinse phase heats up to above 60C and keeps the temperature high for a minimum of 10 minutes to sanitize your dishes.

EFFORTLESSLY DRIED DISHES
Unload dry dishes with TemperatureDry. This function transforms moisture on dishes into steam, which is expelled from the dishwasher to prevent re-condensation resulting in drying.

SWITCH TO ECO
Suitable for cleaning normally soiled tableware, the Eco Program is this dishwashers most efficient program for water and energy consumption.

SAVE TIME, ENERGY, AND WATER
The AutoFlex program adjust wash settings by using sensors to deliver a tailored cycle for the load according to soil level. This save times, energy, and water.

FLEXIBILITY TO ADD MORE
You never have to wash your tall kitchenware by hand again. The height of the upper basket can be easily adjusted, giving you the flexibility to fit larger, bulkier items of any height with greater convenience.

CLEAN DISHES ON YOUR SCHEDULE
The 9-hour delay start function lets you load your dishwasher and program it to start at the time that suits your schedule.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Type of Dishwashers	freestanding
Place settings	13
Drying system	turbo dry
Number of spray arms	2
Top shower	No

SPECIFICATION

Water Efficiency Star Rating	5
Water consumption (litres)	10.7
Energy Efficiency Star Rating	3.5
Energy consumption cold water (kWhr/yr)	255
Noise level dBA	46
Water supply	cold or hot (maximum 60°C)
Basket colour	grey
Service cord length	180

DIMENSIONS

Total height (mm)	850
Total width (mm)	598
Total depth (mm)	598

WASH PROGRAMS

Number of Programs	6
Programs	fast 30min,pre-wash,Eco 50°C,Time Save 50 minutes,Hygiene 70°C,AutoFlex

DIMENSIONS

Height adjustment (mm)	20

WASH PROGRAMS

Wash option	Half Load,Extra hygiene

CONTROL PANEL

Control panel type	Push button electronic
Control panel finish	black
Knob or button finish	black
Display indicators	wash program,rinse aid,on/off ,program selected,lock,tablet function,delay start,half load ,Self Clean,End

FEATURES

Other Features	delay start,Soil Level Sensor,child lock on control panel,Self Clean
Water safety system	overfill protection,aqua control
Filter system	3 stage
Dispenser	detergent,rinse aid
Number of spray levels	2

EXTERIOR

Door finish	stainless steel
Side colour	grey
Plinth colour (kickboard)	stainless steel

UPPER BASKET

Upper basket features	adjustable top basket
Foldable cup shelves	4

LOWER BASKET

HOSES

LOWER BASKET

Lower Basket Features	Modular Cutlery Basket
Foldable Racks	4

HOSES

Inlet hose length	170
Drain hose length	180
Inlet hose length (metres)	1.70
Drain hose length (metres)	1.80

SHIPPING


Shipping Weight (Kg)	48
Pack Dimensions Height (mm)	881
Pack Dimension Width (mm)	644
Pack Dimension Depth (mm)	661

STUFFING QUANTITIES

20ft	48
40ft	102
40ft HC	153

Dimensions

Model:
ESF6604XB



© 2023 Electrolux S.E.A PTE. LTD. ELX_IM_Diag_ESF6604XB_Dec23

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA
telephone: 1300 363 640
fax: 1800 350 067
email: customercare@electrolux.com.au
web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND
telephone: 09 573 2230
fax: 09 573 2221
email: customercare@electrolux.co.nz
web: www.electrolux.co.nz