

60cm fully integrated dishwasher with MaxiFlex™, SprayZone, AirDry technology, beam on floor indicator, 15 place settings.





Product Details

FEATURES

MaxiFlex MaxiFlex drawer space can be adapted to the load. SprayZone SprayZone directs high pressure water for flawless results. Glass care SoftGrips and SoftSpikes delicately hold glasses. SatelliteClean SatelliteClean reaches all items with water jets.

PerfectFit sliding hinges PerfectFit hinges adapt to any door and plinth* AirDry Allows natural airflow in towards the end of the cycle ensuring dry dishes Beam on Floor Beam-on-Floor shows you when its time to unload.

BENEFITS

MAKE ROOM FOR MORE

The MaxiFlex drawer accommodates everything from spoons to spatulas. From multiple cutlery sets to over-sized utensils, the flexible dividers mean you can customise the drawer according to the load. Flatware is kept separate from larger items and the added depth increases the capacity for each cycle.

ALL CORNERS REACHED

The SprayZone function intensively cleans your cookware, with three-times better cleaning performance compared to our standard program. You don't need to pre-soak your heavily soiled dishes. The powerful water pressure brilliantly cleans everything placed within the dedicated space, every time.

THE GLASS-CARE SPECIALIST

SoftGrips and SoftSpikes gently support your delicate glasses, safeguarding them from damage, while the dedicated glassware program means you no longer have to hand wash. SoftGrips gently secure each individual glass stem, while the rubber SoftSpikes cushion glassware from vibration during the wash cycle so they do not move around.

MAX COVERAGE. MAX CLEAN

SatelliteClean shoots multiple jets of water into every corner of the dishwasher to ensure every item is thoroughly cleaned. The double rotation movement continuously changes the angle of the water jets to ensure maximum coverage, delivering outstanding cleaning results.



INTUITIVE AND TAILORED CYCLE

MyTime is the effortless and intuitive way to start your tailored dishwashing cycle. Pick the cycle time with the slider and add any optional treatments with just a tap - it's never been simpler. Then, sit back and let the machine do the rest.

A PERFECTFIT FOR ANY KITCHEN

Double rotation PerfectFit hinges allow you to install the dishwasher with any door length, without needing to cut your kitchen plinth*. The special movement of the double fulcrum hinges makes it possible to open the dishwasher door with ease.

UP TO 3X BETTER DRYING*

AirDry technology finishes each cycle with a breath of fresh air, performing three-times better than closed-door systems. The door automatically opens 10 cms towards the end of the drying phase, without you lifting a finger. This allows air to circulate inside, leaving plates and cutlery completely dry and spotless at the end of the cycle, whilst also saving energy.* Compared with our closed system.

STATUS CHECK FROM A DISTANCE

Beam-on-Floor projects the status of your wash program so that you can easily see when its time to unload. A red spot on the floor means that the program is still running, while a green spot means that it is completed.



Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Type of Dishwashers	fully integrated
Place settings	15
Drying system	AirDry
Number of spray arms	3
Top shower	Yes

SPECIFICATION

Water Efficiency Star Rating	5
WELS Registration Number	D02712
Water consumption (litres)	12.2
Energy Efficiency Star Rating	4
Energy consumption cold water (kWhr/yr)	246
Noise level dBA	44
Water supply	cold or hot (maximum 60°C)
Basket colour	grey
Service cord length	1800
Inverter system	Yes

DIMENSIONS

Total height (mm)

818

BUILT-IN DIMENSIONS

Door panel minimum weight 2 (kg)

Electrolux

DIMENSIONS

WASH PROGRAMS

Total width (mm)	596
Total depth (mm)	570

BUILT-IN DIMENSIONS

Door panel maximum 10 weight (kg)

CONTROL PANEL

8	Control panel type	Touch Control electronic
Quick 30 min,Regular 90 min,AUTO Sense,Machine Care,rinse and hold,Light	Top mounted control panel	Yes
60 min,Heavy 160 min,ECO 180 min	Control panel finish	black
Delay start (1-24 hours),SprayZone,GlassCare,ExtraPower	Display indicators	delay start,Beam On Floor Two Coloured,time remaining,service
4		code,rinse aid,program selected,ExtraPower,My Time
	Quick 30 min,Regular 90 min,AUTO Sense,Machine Care,rinse and hold,Light 60 min,Heavy 160 min,ECO 180 min Delay start (1-24 hours),SprayZone,GlassCare,ExtraPower	Quick 30 min,Regular 90 min,AUTO Top mounted control panel Sense,Machine Care,rinse and hold,Light Control panel 60 min,Heavy 160 min,ECO 180 min Control panel finish Delay start (1-24 hours),SprayZone,GlassCare,ExtraPower Display indicators

FEATURES

Other Features	beam on floor indicator,delay start,Auto Off,Soil Level Sensor,MaxiFlex cutlery drawer
Water safety system	aqua control
Dispenser	detergent,rinse aid

EXTERIOR

Door finish	your cabinetry
Side colour	grey
Plinth colour (kickboard)	no plinth supplied
Removable worktop	No



UPPER BASKET

Upper basket features	soft spikes for tall glass,SoftGrip,Foldable glass rack,easy lift adjustable upper basket
Foldable cup shelves	4
Foldable Racks	2

LOWER BASKET

Lower Basket Features	SprayZone
Foldable Racks	4
Foldable cup shelves	0

HOSES

Inlet hose length	1800	
extension hose	spare part	

SHIPPING

Shipping Volume (m3)	0.376
Shipping Weight (Kg)	40.1
Pack Dimensions Height (mm)	870
Pack Dimension Width (mm)	635
Pack Dimension Depth (mm)	680

STUFFING QUANTITIES

40ft HC


150





Dimensions

Model: ESL79200RO



© 2022 Electrolux S.E.A PTE. LTD. E_DIm_ESL79200RO_Apr22



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067 email: customercare@electrolux.com.au web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND telephone: 09 573 2230 fax: 09 573 2221 email: customercare@electrolux.co.nz web: www.electrolux.co.nz