

Universal White Silicone Appliance Mat - 60cm





Product Details

FEATURES

Absorb machine vibrations during operation

Moisture proof and heat resistant durable construction

Anti-slip surface

Made of durable white silicone, blending seamlessly into your laundry or kitchen space

BENEFITS

Suitable for most brands

Suitable for most Front Load and Top Load Washing Machines, Dryers, Washer/Dryer Combos and Dishwashers

Anti-slip surface

The non-slip surface provides a practical solution to storing a laundry basket on top of your machine, whilst protecting the surface of your machine.

Protects your floors from damage

It's resistant durable construction provided a cushioned surface that is moisture proof and heat resistant. Providing padding and protection to your floors.

Reduce noise in your laundry or kitchen space

The mat surface is designed to absorb the vibration from your appliance during operation to reduce noise.



Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)

Product Relates to Washing Machine, Dryer

Install, Perform, Care Install

FEATURES

Accessory Other Features

Durable construction, Easy to clean, Universal, Suitable for models from most brands, May require assistance moving appliances when installing, Noise reducing, Reduce vibration, Non-slip surface

SPECIFICATIONS

Material	TPR	

DIMENSIONS

Total height (mm)	3
Total width (mm)	600
Total depth (mm)	600

SHIPPING

Shipping Weight (Kg)	1.49
Pack Dimensions Height (mm)	640
Pack Dimension Width (mm)	640



SHIPPING

Pack Dimension Depth (mm)

5



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230 fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz