

Universal Anti-Vibration Pads 4-Pack



Product Details

FEATURES

Quick and easy to install

Protects your floors from damage

Minimises noise and vibration

BENEFITS

Quieter load

The cushioned pads absorb the vibrations from your machine during operation, reducing the noise and movement for a quieter load.

Easily position under your machine

Each pack contains 4 pads, which measure 65mm in diameter and 20mm in height and can be easily placed and positioned under the feet of your machine.

Suitable for most brands

Designed to suit most Front Load and Top Load Washing Machines, Dryers & Dishwashers

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs) 1

Product Relates to Dishwasher, Washing Machine, Dryer

Install, Perform, Care Perform

SHIPPING

Shipping Weight (Kg) 0.14

Pack Dimensions Height (mm) 156

Pack Dimension Width (mm) 133

Pack Dimension Depth (mm) 23

FEATURES

Accessory Other Features

Quick & easy installation, Suitable for models from most brands, May require assistance moving appliances when installing, Noise reducing, Reduce vibration, Protect floors

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz