

Universal Activated Carbon Rangehood Filter 2-Pack



Product Details

FEATURES

Genuine filter for selected
Chef and Westinghouse
rangehoods

Captures unwanted odours

BENEFITS

Cook in Comfort
Let your range hood do all the work so you can enjoy cleaner,
fresher air in your kitchen.

Keep kitchen airborne pollutants at bay with activated carbon
The activated carbon contained in the filter works to capture
odours, oils & grease released whilst cooking, preventing
them from entering the kitchen. Keeping your air flow fresher
for longer.

Genuine range hood filter replacement
Carbon filter made specifically for selected Westinghouse and
Chef range hoods

Easy quarterly replacement for optimal performance
It is recommended that you replace your filter every 3-4
months, or as required, depending on the style and frequency
of cooking.

Quick and easy filter installation
It's as simple as 'twist and replace' with your new replacement
filter.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	1
---------------------------------	---

Product Relates to	Rangehood
--------------------	-----------

Install, Perform, Care	Perform
------------------------	---------

SHIPPING

Shipping Weight (Kg)	0.6
----------------------	-----

Pack Dimensions Height (mm)	278
-----------------------------	-----

Pack Dimension Width (mm)	200
---------------------------	-----

Pack Dimension Depth (mm)	63
---------------------------	----

FEATURES

Accessory Other Features	Quick & easy installation, Model specific - check for compatibility, Remove cooking odours and oil particles
--------------------------	--

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz