Universal Activated Carbon Rangehood Filter 2-Pack



Product Details

FEATURES

Captures unwanted odours

Genuine filter for selected Chef and Westinghouse rangehoods

BENEFITS

Cook in Comfort Let your range hood do all the work so you can enjoy cleaner, fresher air in your kitchen.	Keep kitchen airborne pollutants at bay with activated carbon The activated carbon contained in the filter works to capture odours, oils & amp; grease released whilst cooking, preventing them from entering the kitchen. Keeping your air flow fresher for longer.
Genuine range hood filter replacement Carbon filter made specifically for selected Westinghouse and Chef range hoods	Easy quarterly replacement for optimal performance It is recommended that you replace your filter every 3-4 months, or as required, depending on the style and frequency of cooking.

Quick and easy filter installation It's as simple as 'twist and replace' with your new replacement filter.

Specifications

PRODUCT PROFILE

Domestic warranty details	1
(yrs)	

Product Relates to	Rangehood
Install, Perform, Care	Perform

FEATURES

Accessory Other Features Quick & easy installation,Model specific check for compatibility,Value pack

SPECIFICATIONS

Material

Carbon

SHIPPING

Shipping Weight (Kg)	0.33
Pack Dimensions Height (mm)	265
Pack Dimension Width (mm)	200
Pack Dimension Depth (mm)	63

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067 email: customercare@electrolux.com.au web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND telephone: 09 573 2230 fax: 09 573 2221 email: customercare@electrolux.co.nz web: www.electrolux.co.nz