

2 in 1 cordless vacuum cleaner with 180° EasySteer™ manoeuvrability and BrushRollClean™ that gives you the feeling of clean, everyday.



Product Details

FEATURES

Self standing feature

Allows you to leave the clear upright if a need arises

Dustspotter LED lights

Brush roll clean

180 Easysteer™

for an easy glide on all floors

2 in 1 detachable handheld

BENEFITS

Lithium TurboPower

Ergorapido features high performance Lithium TurboPower battery for optimal cleaning performance and longer run time (up to 35 minutes on low speed). The LED battery indicator shows when its time to recharge.

BrushRollClean™ technology

Our unique BrushRollClean™ technology saves you the trouble of having to clean the brush roll with your hands or scissors. An internal blade removes entwined hairs and fibres before they are vacuumed into the dust cup, all with the push of a button.

Easy to use

The 180-degree swivel nozzle means smooth turning and manoeuvrability on all floors. With an ergonomic design and low centre of gravity, this lightweight vacuum cleaner is very easy to use.

2 in 1 vacuum cleaner

Stick vacuum and hand held unit in one. Clean above the floor with the detachable handheld unit, ideal for furniture, shelves and table tops.

Specifications

MAIN

Brand Electrolux

Product Type Instant

PNC 900943271

EAN/UPC 7332543734535

Model/Part number ZB3501WR

Replaces model ZB3107

Description Ergorapido 14.4V
Watermelon Red

Vacuum Bag/Bagless Bagless

Warranty Period 2 years

TECHNICAL SPECIFICATIONS

Volt (V) 14.4

Battery cell, type Li-ION

DESIGN

Main colour Watermelon Red

ACCESSORIES / NOZZLE

Accessories No

PACKAGING & LOGISTICS

SINGLE PACKAGE

Gross weight (kg)	4.15
Package width (mm)	299
Package depth (mm)	165
Package height (mm)	689

OUTER CARTON

Units in outer	2
Gross weight (kg)	9
Package width (mm)	339
Package depth (mm)	313
Package height (mm)	700
Max units in 20 ft cont.	708
Max units in 40 ft cont.	1464

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This appliance is warranted against manufacturing defects in Australia and New Zealand for 24 months following the date of original purchase of the Appliance, where the Appliance is used for personal, domestic or household use (i.e. normal single family use) as set out in the instruction manual. Where the Appliance and accessories (including nozzles, brushes or other cleaning attachments) are used for commercial purposes, the Appliance will then be warranted against manufacturing defects in Australia for 3 months and in New Zealand for 3 months, following the date of original purchase of the Appliance.

ELECTROLUX FLOOR CARE & SMALL APPLIANCES AUSTRALIA

telephone: 1300 366 366

fax: 1800 673 326

email: info@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX FLOOR CARE & SMALL APPLIANCES NEW ZEALAND

telephone: 05 08 730 730

fax: 09 573 2382

email: floor.care@electrolux.co.nz

web: www.electrolux.co.nz