609L UltimateTaste 900 french door fridge, dark stainless with FlexFresh fully convertible entertainer's drawer, TasteLockAuto Easy-glide crispers with automatic humidity control, Slide-back and Flip-up shelves and in door ice & water dispenser



Product Details

FEATURES

FlexFresh™ Fully Convertible Entertainer's Drawer	SmartSplit Door Design	Connectivity	Mark resistant real stainless steel
Filtered ice and water	Slide-back and Flip-up shelving	SnackZone	UltraChill
Drinks Storage	Snacks Storage	FlexStor	FreshPlus Cooling Keep your food at its best with our innovative FreshPlus technology. Whenever the fridge door is open, it immediately begins recooling to replace the lost cold air.
Quick freeze function great for when a large quantity of food is added to the freezer	Boost mode After a large grocery shop, use the Boost function when adding food to your fridge, so that the temperature decreases for 90 minutes before returning to the pre-set mode.	TwinTech Cooling System	Electronic controls with LED display and acoustic signal Electronic controls with LED display and acoustic signal
Holiday mode Going away? Set the fridge to Holiday Mode to help minimise defrosting and save energy.	R600a refrigerant better for the environment	LED lighting	Frost free Save your precious time with a freezer that doesn't ice up and need manual defrosting.

Fresh Sense deodoriser
Keep your fridge and its contents smelling fresh with the in-built Fresh Sense deodoriser.

BENEFITS

Understanding new capacity and energy ratings
From the 15th August 2021, the way refrigerators are tested to calculate Energy Star Ratings and energy consumption have changed. This means that the capacity and energy rating calculations have changed, however the product remains unchanged. Be sure to check all new ratings to ensure that your comparisons are consistent with the new standards.

A place for everything
We've thought long and hard about what you need in a fridge. Which is why you'll find a host of ingenious zones to help you organise your drinks and other items and even adjust micro-temperatures for perfect cooling. The FlexFresh fully convertible entertainer's drawer lets you dial up or down the cold air from -23C to +7C so your creation is revealed at its best. Likewise, you can store your drinks in the special drawer and set the temperature for perfectly chilled champagne or ice-cold drinks. Store your go-to essentials in a special SnackZone for the ultimate in organisation.

Intuitive door design
With optimally split doors you have more usable space in your refrigerator door and can effortlessly reach for larger items, saving you the need to open both doors every time.

Fresh is best
Our innovative TasteLock crispers automatically control the humidity levels to keep your fruit and vegetables at their best for longer. While Easy-glide crisper drawers open effortlessly, even when they're full.

Stylish and smart
High quality, mark-resistant real stainless steel, now available in a new chic dark hue or classic natural stainless steel, lends a touch of class to any kitchen. Inside, the generous interior marries innovation and style in equal measure.

Connectivity
Fresh ingredients form the most important part of every meal. With the new Electrolux Life app, you can confidently know that your produce is in the desired conditions by being able to monitor & adjust its temperature from the palm of your hand. Set your Entertainers Drawer to the right temperature when you're out gathering fresh produce, and receive alerts through the app when the desired temperature is reached. Ensure you always have fresh filtered water, as you get a reminder when its time to change the filter cartridge, or an alert when the door is accidentally left open. Let the refrigerator do the thinking so you can effortlessly plan your next get together.

Connectivity Terms and Conditions
Minimum requirements:Minimum requirements : Apple iOS11.1 / Android 7.0 and above. You will need to install the Electrolux Life app, create an Electrolux account and accept the Terms and Conditions and Electrolux's Privacy Policy in the app to use the connected features of the appliance. Internet and Wi-Fi connections are required to use the full features of the app and the appliance. Minimum requirements, apps and services are subject to change without notice.

Thirst-quencher
Like a cool glass of pure, filtered water? Your fridge is there to deliver, any time of the day or night at the touch of a button.

Ice on the go
You'll love the efficient, always-ready ice-maker in your new fridge. Efficient and compact, it's ideal for hot summer days or effortless entertaining.

Smart on space
The thoughtful Slide-back and Flip-up shelving means you can store that two-tiered birthday cake for the big moment, no problem.

SnackZone
The SnackZone is the ideal compartment for keeping those smaller ingredients separate for easy access such as fruit for your morning smoothie allowing you to be prepared before the week begins.

Designed just for you
Customise your fridge just the way you want it. FlexStor™ makes it simple to arrange the fridge to your needs with adjustable door bins and shelves. Different sized compartments effortlessly accommodate items big or small.

Keep it cool
The fridge door is one of the most opened in any household, which is why we came up with FreshPlus technology to help maintain the perfect temperature inside your fridge. It automatically detects when it needs to begin cooling, keeping the temperature down to lock the freshness in.

Increase the chill
With a combination of Quick Freeze and Boost mode, you will always be prepared when entertaining. After a large shop, Boost Mode increases the chill rate of the refrigerator for 6 hours whilst the Fast Ice function lowers the freezer to -23C for 12 hours, before returning to their pre-set temperatures, to ensure your produce stays fresher longer.

UltraChill
The UltraChill setting is a deep chill at -2C which keeps meat and fish fresh in optimum condition for longer without freezing. This ensures the fresh texture is maximised and moisture loss is reduced compared to regular deep freezing. This saves your time defrosting meat and more time to enjoy with your guests.

Snacks Storage
Store your specialty meats and cheese at 3C, the ideal temperature for storing your antipasto platter, ready to be enjoyed when your guests arrive.

Drinks Storage
Store your drinks at the ideal temperature every time by setting the drawer at 7C for perfectly chilled wine and champagne, or at 0C for icy cold drinks.

Effortless access
It is one of the most hardworking appliances in your house, so it makes sense your fridge takes the effort out of simple tasks. Our smooth telescopic runners ensure you can reach the very back of the crisper and freezer drawers easily.

TwinTech Cooling System
Two independent cooling systems work together to deliver lasting freshness. One cooling system chills the freezer so no frost builds up. The other cools the refrigerator, providing stable temperature and humidity.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Additional domestic warranty for the sealed refrigeration system only (yrs)	3
Refrigerator Type	french door
Exterior door finish	dark stainless steel
Handle design	integrated
Fridge door opening	left and right
Cooling system	frost free
Freezer door opening	drawer
Refrigerant	R600a
Dispenser type	ice and water
Plumbed water supply required	Yes

DIMENSIONS

Total height (mm)	1782
Cabinet height (mm)	1756
Total width (mm)	913
Cabinet width (mm)	908
Total depth (mm)	746
Cabinet depth (mm)	625
Depth door open 90degree (mm)	1189
Air space above cabinet (mm)	25
Food Compartment Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	371
Freezer Compartment Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	165
Convertible Compartment Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	73
Total Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	609

DIMENSIONS

Food compartment capacity (gross in litres)	413
Freezer compartment capacity (gross in litres)	188
Convertible Compartment/Drawer capacity (gross in litres)	80
Total Gross Capacity (L)	681
Food compartment capacity (net in litres)	363
Total Net Capacity (L)	541

ENERGY

Energy Star Rating - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	3.5
Energy Consumption (kWh/year) - AS/NZS 4474.1 2007 (IEC 62552-2015) *	501
Energy Star Rating AS/NZS 4474.2:2009	3
Energy consumption AS/NZS 4474.2:2009 (kWhr/yr)	560

REFRIGERATOR SYSTEM

Controls	electronic (with display)
Controls location	internal
Controls type	touch
Control functions	quick freeze function,quick chill,lock,ice maker,wi-fi connected
Door alarm	fridge and freezer

FOOD COMPARTMENT

SHELVING

Shelf material	glass
Type of shelf	spill safe shelf,adjustable shelf
Flip up shelf	1
1/3 width shelves	1
2/3 width shelves	1

CRISPERS

Crisper lid/shelf	plastic
Crispers Runner system	telescopic
Crisper features	automatic humidity control,fully sealed
1/3 width crisper	1
2/3 width crisper	1

LIGHTING

Feature lighting	LED
Main light	LED

OTHER PROPERTIES

Other Properties-FOOD COMPARTMENT	Egg tray,Snack zone

FOOD COMPARTMENT DOOR

BINS

Deep bottle bin	1
Shallow bin	2
1/3 width bins	1

DAIRY COMPARTMENT

Half width, with lid	1

Expandable bin	1

SPECIAL COMPARTMENTS

Small items bin	1

EXTERNAL

Dispenser through door	ice and water

FREEZER COMPARTMENT

ICE FACILITY

Ice Maker	Automatic


BASKET/DRAWER

Full width plastic basket	1
Basket/Drawer runner system	telescopic
Drawer divider	2
Full width deep plastic basket	1


LIGHTING


Main light	LED

Dimensions




Minimum Recommended Airspaces






Please note: Doors are designed to sit proud of cabinetry (not flush)



Front face of bench aligned to front corner edge of cabinet.



When positioned In a corner area, spacing of at least 310mm on the right hinge side and 219mm on the left hinge side will allow the doors to open enough to enable the removal of bins and shelves.

Dimensions	Product Height	Product Width	Product Depth	Product Depth (Door Open)
EHE6899BA	1782	913	746	1189
EHE6899SA	1782	913	746	1189

Airspace	Side - both	Top	Behind
EHE6899BA	10	25	35
EHE6899SA	10	25	35

For connection kit installation instructions go to electrolux.com.au

Important! Please ensure that the access to your kitchen (including doorways, corridors, island benches, etc) allows sufficient clearance to move your fridge into position.

Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions.

© 2021 Electrolux Home Products Pty Ltd. E_DIM_EHE6899BA-SA_Sep21

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA
telephone: 1300 363 640
fax: 1800 350 067
email: customercare@electrolux.com.au
web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND
telephone: 09 573 2230
fax: 09 573 2221
email: customercare@electrolux.co.nz
web: www.electrolux.co.nz