**70cm 4 zone induction cooktop with maxisense zone flexibility, 14 stage slide controls, power boost and stop & go function.**



# Product Details

## FEATURES

| | | | |
|---|---|---|---|
| Selected stockists only<br>Only available at selected Good Guys, Domayne, Harvey Norman and Joyce Mayne stores. | High performance induction technology | Residual heat indicators all zones<br>Indicates which area is too hot to comfortably touch. | Timer |
| Minute minder | Auto warm-up function | STOP + GO function | Touch and slide controls<br>Touch the control bar at the necessary heat setting |
| Child safety device | Acoustic signal<br>Confirms use of the control panel | | |

## BENEFITS

High performance induction technology
Have complete control with precise cooking. Cook from simmer to a boil instantly while using induction technology. Providing the ultimate in safety induction cooking generates heat in the cookware, so surfaces around the pot are cool to touch. The cooking environment remains cooler and is therefore safer too. The surface is also easy to clean, as spills can be simply wiped away.

Maximum flexibility
Maxisense induction cooktops are developed with three or four extra large zones, which detect pan presence and location and are not restricted to traditional circular zones

Professional results
Maxisense Induction combines the speed of gas with the addition of precise control. A range of cooking zones allow the cook to prepare any sized meal faster with a more consistently high quality

Intuitive
Maxisense cooktops are easy to use and intuitive featuring touch and slide control. Simply slide your finger along the glass surface to change cooking temperature instantly

Ultimate in safety and comfort
Induction cooking generates heat in the cookware, so surfaces around the pot are cool to touch, and the cooking environment remains cooler. The surface is also easy to clean, as spills are simply wiped away

# Specifications

## PRODUCT PROFILE

| | |
|---|---|
| Domestic warranty details (yrs) | 2 |
| Cooktop type | induction |
| Materials/Colour | black |
| Removable trim (for cleaning) | No |
| Wok included designed to fit cooktop | No |

## DIMENSIONS

| | |
|---|---|
| Total product height (mm) | 55 |
| Total product width (mm) | 710 |
| Total product depth (mm) | 520 |
| Cut out width (mm) | 680 |
| Cut out depth (mm) | 490 |

## CONTROLS

| | |
|---|---|
| Controls of Cooktops | slide touch pad |
| Position of controls | front |
| Functions of Cooktops | stop and go,automatic warm up,timer,Keep warm function,auto heat up,cooking timer with acoustic signal,acoustic signal,booster,automatic switch off,power booster |
| Indicators/display | fault indicator,residual heat warning lamps,3 level residual heat indicator |

## ELEMENTS/BURNERS

### LEFT FRONT ZONE

| | |
|---|---|
| Left front zone | induction extended |
| Left front Watts | 2300 |
| Left front boost watts | 3200 |
| Left front diameter mm | 210 |

## CONTROLS

| | |
|---|---|
| Features of Cooktop | safety cut off,overheating protection,electronic timer,minute minder,function lock,hot surface indicator,automatic pan sensing,safety child lock,pot sensors |
| Timer of Cooktop | programmable 99min,auto off,countdown,CountUp |
| Readable temperature setting | No |

## LEFT REAR ZONE

| | |
|---|---|
| Left rear zone | induction extended |
| Left rear watts | 2300 |
| Left rear diameter mm | 210 |

## RIGHT FRONT ZONE

| | |
|---|---|
| Right front zone | induction extended |
| Right front Watts | 2300 |
| Right front diameter mm | 210 |

## RIGHT REAR ZONE

| | |
|---|---|
| Right rear zone | induction extended |
| Right rear watts | 2300 |
| Right rear diameter mm | 210 |


## ELECTRICAL SPECIFICATIONS


| | |
|---|---|
| Connected load KW | 7.4 |
| Type of connection | hardwired |

# Dimensions

**Dimensions**

| | width | height | depth |
|---|---|---|---|
| Cut-out (mm) | 680 | | 490 |
| Product (mm) | 710 | 55 | 520 |



# Terms and Conditions

**IMPORTANT**

**This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.**

**PRODUCT INFORMATION**

**The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.**

**WARRANTY**

**This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.**

**ELECTROLUX HOME PRODUCTS AUSTRALIA**
**telephone: 1300 363 640**
**fax: 1800 350 067**
**email: customercare@electrolux.com.au**
**web: www.electrolux.com.au**

**ELECTROLUX HOME PRODUCTS NEW ZEALAND**
**telephone: 09 573 2230**
**fax: 09 573 2221**
**email: customercare@electrolux.co.nz**
**web: www.electrolux.co.nz**