


# UNILUX

## Universal Laundry Pedestal with Locking Drawer

### Installation instructions



UNIVERSAL ACCESSORY  
MODEL: ULX110


## Important Information that may impact your Manufacturer's Warranty.

Adherence to the directions for use in this manual is extremely important for health and safety. Failure to strictly adhere to the requirements in this manual may result in personal injury, property damage and affect your ability to make a claim under the Unilux manufacturer's warranty provided with your product. Products must be used, installed and operated in accordance with this manual. You may not be able to claim on the Unilux manufacturer's warranty in the event that your product fault is due to failure to adhere this manual.

## Safety Information


### WARNING

Do not stack a dryer on top of washing machine if using a pedestal.



### WARNING

Do not install it alone.




### WARNING







Before proceeding with installation, make sure there is enough room.

## Product & Accessories Information

### Dimension




### Accessories

- A**  4 x locking brackets
- B**  4 x adjustable feet with lock nuts
- C**  4 x bolts
- D**  4 x spring washers
- E**  4 x flat washers
- F**  2 x keys

## Universal Laundry Pedestal with Locking Drawer

### Installation Procedure


1. Remove the pedestal and all accessories from the box.
2. Fit the four (4) feet to the pedestal and adjust to make it stable.



3. If you install the pedestal under a brand new appliance, unpack the appliance as indicated in the instructions supplied with it then proceed with step 5.
4. If the appliance is already connected:
  - Disconnect the mains plug from the mains socket.
  - For washing machine. Close the water tap.


- For washing machine.  
Disconnect the inlet hose(s) from the water tap and let the water flow out from the inlet hose(s) and the drain hose and collect it in a shallow basin.

- For tumble dryer. Empty the water container in a wash basin or, if available, activate the direct drain system to let the water flow out.




**5. Fit the locking brackets.**


- a. Assemble the bolt **C**, spring washer **D** and flat washer **E** for each bracket.
- b. Fit each of the four (4) locking brackets **A** with the pointed section facing inwards.
- c. Screw in the assembled bolt only until finger-tight, loose enough to adjust later.




- 6. Adjust the appliance feet at a suitable height to allow them to slide under the foot locking brackets.**



- 7. Lift the appliance onto the pedestal so that the appliance front feet slide under the foot locking brackets. Tighten the bolts securing the fast locking brackets, ensuring the bracket is firmly against each feet of the appliance.**



8. Move the Pedestal/Appliance assembly to its permanent location. Use a spirit level to check if the assembly is properly leveled. If not leveled, adjust feet to level properly.



9. Connect the appliance as indicated in the instructions supplied with the appliance.



# Electrolux Warranty

FOR SALES IN AUSTRALIA AND NEW ZEALAND  
APPLIANCE: UNILUX ACCESSORIES

**This document sets out the terms and conditions of the product warranties for Unilux Accessories. It is an important document. Please keep it with your proof of purchase documents in a safe place for future reference should there be a manufacturing defect in your Product. This warranty is in addition to other rights you may have under the Australian Consumer Law.**

## 1. In this warranty:

- (a) 'ACL' or 'Australian Consumer Law' means Schedule 2 to the Competition and Consumer Act 2010;
- (b) 'Product' means any Electrolux spare part and accessory product purchased by you and accompanied by this document;
- (c) 'ASPD' means Electrolux's Authorised Spare Parts Distributor;
- (d) 'Electrolux' is the brand controlled by Electrolux Home Products Pty Ltd of 163 O'Riordan Street, Mascot NSW 2020, ABN 51 004 762 341 in respect of Products purchased in Australia and Electrolux (NZ) Limited (collectively "Electrolux") of 3-5 Niall Burgess Road, Mount Wellington, in respect of Products purchased in New Zealand;
- (e) 'Warranty Period' means the period specified in clause 3 of this warranty;
- (f) 'you' means the purchaser of the Product not having purchased the Product for re-sale, and 'your' has a corresponding meaning.

**2. Application:** This warranty only applies to new Products, purchased and used in Australia or New Zealand and is in addition to (and does not exclude, restrict, or modify in any way) other rights and remedies under a law to which the Products or services relate, including any non-excludable statutory guarantees in Australia and New Zealand.

**3. Warranty Period:** Subject to these terms and conditions, this warranty continues for a period of 12 months in Australia and New Zealand, following the date of original purchase of the Product.

**4. Repair or replace warranty:** During the Warranty Period, Electrolux or its ASPD will, at no extra charge, subject to these terms and conditions, repair or replace any Product or parts which it considers to be defective. Electrolux may, in its absolute discretion, choose whether the remedy offered for a valid warranty claim is repair or replacement. Electrolux or its ASPD may use refurbished parts to repair your Product. You agree that any replaced Products or parts become the property of Electrolux.

**5. Travel and transportation costs:** Subject to clause 7, Electrolux will bear the reasonable cost of transportation, travel and delivery of the Product to and from Electrolux or its ASPD. Travel and transportation will be arranged by Electrolux as part of any valid warranty claim.

**6. Proof of purchase** is required before you can make a claim under this warranty.

**7. Exclusions:** You may not make a claim under this warranty unless the defect claimed is due to faulty or defective parts or workmanship. This warranty does not cover:

- (a) light globes, batteries, filters or similar perishable parts;
- (b) parts and Products not supplied by Electrolux;
- (c) cosmetic damage which does not affect the operation of the Product;
- (d) damage to the Product caused by:
  - (i) negligence or accident;

- (ii) misuse or abuse, including failure to properly maintain or service;
- (iii) improper, negligent or faulty servicing or repair works done by anyone other than an Electrolux authorised repairer or ASPD;
- (iv) normal wear and tear;
- (v) power surges, electrical storm damage or incorrect power supply;
- (vi) incomplete or improper installation;
- (vii) incorrect, improper or inappropriate operation;
- (viii) insect or vermin infestation;
- (ix) failure to comply with any additional instructions supplied with the Product;

In addition, Electrolux is not liable under this warranty if:

- (a) the Product has been, or Electrolux reasonably believes that the Product has been, used for purposes other than those for which the Product was intended, including where the Product has been used for any non-domestic purpose;
- (b) the Product is modified without authority from Electrolux in writing;
- (c) the Product's serial number or warranty seal has been removed or defaced.

**8. How to claim under this warranty:** To enquire about claiming under this warranty, please follow these steps:

- (a) carefully check the operating instructions, user manual and the terms of this warranty;
- (b) have the model and serial number of the Product available;
- (c) have the proof of purchase (e.g. an invoice) available;
- (d) telephone the numbers shown below.

**9. Australia:** For Products and services provided by Electrolux in Australia: Electrolux goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Product repaired or replaced if the Product fails to be of acceptable quality and the failure does not amount to a major failure. 'Acceptable quality' and 'major failure' have the same meaning as referred to in the ACL.

**10. New Zealand:** For Products and services provided by Electrolux in New Zealand, the Products come with a guarantee by Electrolux pursuant to the provisions of the Consumer Guarantees Act, the Sale of Goods Act and the Fair Trading Act. Where the Product was purchased in New Zealand for commercial purposes the Consumer Guarantee Act does not apply.

**11. Confidentiality:** You accept that if you make a warranty claim, Electrolux and its agents including ASPD may exchange information in relation to you to enable Electrolux to meet its obligations under this warranty.

## Important Notice

Before calling for service, please ensure that the steps listed in clause 8 above have been followed.

<p><b>FOR SERVICE</b> or to find the address of your nearest customer care centre in Australia <b>PLEASE CALL 1300 363 640</b> <small>For the cost of a local call (Australia only)</small></p>	<p><b>AUSTRALIA</b> ELECTROLUX HOME PRODUCTS 163 O'Riordan Street, Mascot NSW 2020 electrolux.com.au</p>	<p><b>FOR SPARE PARTS</b> or to find the address of your nearest spare parts distributor in Australia <b>PLEASE 13 13 50</b> <small>For the cost of a local call (Australia only)</small></p>
<p><b>FOR SERVICE</b> or to find the address of your nearest authorised service centre in New Zealand <b>PLEASE CALL 0800 10 66 10</b> <small>(New Zealand only)</small></p>	<p><b>NEW ZEALAND</b> ELECTROLUX (NZ) Limited 3-5 Niall Burgess Road, Mount Wellington electrolux.co.nz</p>	<p><b>FOR SPARE PARTS</b> or to find the address of your nearest spare parts centre in New Zealand <b>PLEASE 0800 10 66 20</b> <small>(New Zealand only)</small></p>



For more information on all UNILUX accessories  
call into your retailer, phone or email our customer  
care team or visit our website:

**Electrolux Home Products Pty Ltd**

Phone: 1300 363 640

Email: [customercare@electrolux.com.au](mailto:customercare@electrolux.com.au)

Web: [uniluxaccessories.com.au](http://uniluxaccessories.com.au)

**Electrolux (NZ) Limited**

Phone: 0800 234 234

Email: [customercare@electrolux.co.nz](mailto:customercare@electrolux.co.nz)

Web: [uniluxaccessories.co.nz](http://uniluxaccessories.co.nz)

**UNILUX IS PART OF THE ELECTROLUX FAMILY**